



# Honeywell

## Voyager 1200g Holder Installation




**HOLDER-004-U**

*Note: Screws are optional, but recommended when hard-mounting to a surface.*



**HOLDER-005-W**



1 (888) 238-1155 Inside USA • 1 (205) 383-2244 Outside USA  
info@atlasRFIDstore.com • www.atlasRFIDstore.com

 atlasRFIDstore.com