



Safe – Simple – Effective

- Safely bypass congested, narrow toll booth lanes with open road tolling across the US
- Installs on windshield in minutes
- Battery-powered with 5-year service life under typical use
- No stopping or waiting, because the toll is electronically deducted from your single pre-paid account
- RV Toll Pass account can be automatically replenished

Coverage on over 95% of US Toll Roads

For details and updates, go to rvtollpass.com

TRANSPONDER HAS NO VALUE UNTIL ACTIVATED

To register and activate your RV Toll Pass transponder, and set up your account using a major credit card, go to rvtollpass.com.

Managed by BestPass™, a major nationwide provider of toll support services to the trucking industry.

⚠ WARNING	
<ul style="list-style-type: none"> • INGESTION HAZARD: This product contains a button cell or coin battery. • DEATH or serious injury can occur if ingested. • A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. 	



The Open Road
is **Now More Open**

For Motorhomes and Camper Trailers Single Transponder, Single Account Solution

Universal

Nationwide coverage on most US Toll Roads

Cost Effective

Lower electronic toll rates

Nominal monthly fee charged only when used



Go to rvtollpass.com or see included user manual for frequently asked questions, detailed mounting instructions, current customer agreement, terms and conditions, warranty information, and restrictions.

WELCOME TO RV TOLL PASS!

With one transponder and one account, you can conveniently travel on most major toll roads in the US without stopping at toll booths, while receiving the electronic tolling rate. Visit rvtollpass.com for the most up-to-date information on toll road coverage and use of this revolutionary product. Check your account balance, replenish your account, update account information, order additional transponders, print an activity summary, and more.

INSTALLATION AND USAGE INSTRUCTIONS

Mylar Bag - do not discard!

The mylar bag prevents your RV Toll Pass transponder from being read by toll equipment in your local area. For local driving, you should use a transponder issued by your local toll authority. When a local transponder is in use, store your RV Toll Pass transponder in the mylar bag.

Metallized Windshield

For more information on whether or not your vehicle has a metallized windshield contact your auto dealer.

LOCATION OF TRANSPONDER

Caution: Failure to follow mounting instructions may void warranty.

The RV Toll Pass transponder should be mounted on the interior windshield with the longest side parallel to the top of the windshield. To avoid unexpected costs and double-billing, other RFID Transponders should be disabled when the RV Toll Pass is in use. Windshield sticker tags can be disabled using the included **Tag Shield**.

Windshield with rear-view mirror

Transponder should be mounted on the windshield 2" to the right and 2" below the rear-view mirror post.

Windshield with no rear-view mirror

Transponder should be centered on the windshield, 4" below the top of the windshield.

Two-piece windshield

Transponder should be mounted on the passenger side, 3" away from the center dividing bar and 4" below the top of the windshield.

PREPARE THE MOUNTING SURFACE

Clean and dry the interior windshield surface completely. Windshield temperature should be at least 68°F (20°C) for optimum bonding.

INSTALL THE TRANSPONDER

NOTE: The mylar bag should be saved for storing the transponder when it is not in use.

Remove the transponder from the mylar bag. Keep both sides of the Dual Lock™ strips pressed together to ensure the strips will align between the transponder and windshield. Peel the backing from both Dual Lock™ strips to expose the adhesive. Apply the transponder to the windshield using moderate pressure. The manufacturer recommends leaving the transponder in place for at least 24 hours to allow the adhesive to cure.

REMOVE THE TRANSPONDER

Grip the transponder at the top and bottom sides. Gently lift the transponder away from the windshield on one end until the Dual Lock pieces separate and the transponder is free from the windshield. Store the transponder in a mylar bag.

NO UNAUTHORIZED MODIFICATIONS STATEMENT

Caution: This equipment may not be modified, altered, or changed in any way without permission from TransCore, LP. Unauthorized modification may void the equipment authorization from the FCC and will void the TransCore warranty.

RADIO FREQUENCY INTERFERENCE STATEMENTS

Note: This device complies with Part 15 of the FCC Rules and the Industry Canada Licence-Exempt RSS Standards. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of this device.

FREQUENTLY ASKED QUESTIONS

Are there US toll roads that are not covered by the RV Toll Pass program?

Most major US toll roads are covered by RV Toll Pass; however there are a few (less than 5%) that are not yet in the program. On those roads you will be typically charged a video toll rate and billed by mail based on license plate ID. Please refer to the coverage map on rvtollpass.com for full details.

Will RV Toll Pass work on High Occupancy Toll (HOT) lanes or bridges?

RV Toll Pass is designed to work on most major toll roads in the US, but there are often special local rules for use on HOT lanes that vary from region to region that are subject to change. Some bridges have local rules that are subject to change and may require cash payment only. Please refer to the rvtollpass.com coverage website for further details and recommended use on HOT lanes and bridges. Before you travel, go to the relevant local authorities' web site for the most up-to-date information.

Will I save money using the RV Toll Pass?

Yes! When driving in authorized coverage areas, you will be charged discounted electronic toll rates instead of higher cash or video toll rates. View the coverage map on rvtollpass.com.

What is the battery life for the transponder?

Battery life is typically 5 years if instructions are followed for storage when not in service.

If I am towing a trailer, how will I be billed while using the RV Toll Pass program?

Most agencies will automatically count the trailer axles and bill you automatically on the open road lanes. If a toll agency does not have an automated axle count system, you must use the manual toll lane to ensure that you are not billed as a violator and subjected to fines above the toll rate.

Is there a warranty for the RV Toll Pass transponder?

Yes. 30 days unconditional warranty from time of purchase. One year warranty for parts and materials including battery. Visit rvtollpass.com for warranty questions or returns.

INSTALL TAG SHIELD



Use Tag Shield to temporarily disable your windshield sticker tag when your RV Toll Pass is in use. This will help avoid getting charged twice for the same toll.

Tag Shield easily mounts to your interior windshield. After Tag Shield is set up, it can be easily mounted to the windshield when you do NOT want your windshield sticker tag to be read. When your RV Toll Pass is stored away in its protective mylar bag, remove Tag Shield to enable your windshield sticker tag.

INSTALLATION

1. Use an alcohol wipe to clean the windshield to the left and right of the windshield sticker tag that is mounted to your interior windshield.
2. Peel off the backing from the hook-and-loop strips located on each side of Tag Shield.
3. Position Tag Shield so that it completely covers the windshield sticker tag. Each time that you install Tag Shield, press the hook-and-loop strips so that it fits closely against the windshield sticker tag.

Note: Leave Tag Shield in place for 24-hours to allow the hook-and-loop adhesive to cure. Leave the hook-and-loop on the windshield in place to quickly mount or remove the Tag Shield.

REMOVAL

Grip Tag Shield by its upper and lower handles and pull it away from the windshield. Remember that the hook-and-loop strips that are attached to the windshield should stay in place.

STORAGE

Store Tag Shield in your vehicle's console when it is not in use.